

# product information sheet

Trade Mark	AEG
Model	DTX3840B 942022778
Annual Energy Consumption (kWh/year)	67.9
Energy Efficiency class	C
Fluid Dynamic Efficiency	13.1
Fluid Dynamic Efficiency class	D
Lighting Efficiency (lux/W)	41.34
Lighting Efficiency class	A
Grease Filtering Efficiency	75.1
Grease Filtering Efficiency class	C
Air flow at minimum and maximum speed in normal use (m3/h)	300/500
Air flow at intensive or boost setting (m3/h)	-
Airborne acoustical A-weighted sound power emissions at minimum and maximum speed in normal use (dB(A))	57/69
Airborne acoustical A-weighted sound power emissions at intensive or boost setting (dB(A))	-
Power consumption in standby mode (W)	0
Power consumption in off mode (W)	0.01

## Product information according to Commission regulation (EU) No 66/2014

Attribute Name	Symbol	Value	Unit
Model Denomination		DTX3840B 942022778	
Annual Energy Consumption	AEC <sub>hood</sub>	67.9	kwh/a
Time increase factor	f	1.5	
Fluid Dynamic Efficiency	FDE <sub>hood</sub>	13.1	
Energy Efficiency Index	EEl <sub>hood</sub>	82.6	
Measured air flow rate at best efficiency point	QBEP	261.6	m <sup>3</sup> /h
Measured air pressure at best efficiency point	PBEP	207	Pa
Maximum air flow	Q <sub>max</sub>	500.0	m <sup>3</sup> /h
Measured electric power input at best efficiency point	WBEP	115,0	W
Nominal power of the lighting system	WL	6.7	W
Average illumination of the lighting system on the cooking surface	E <sub>middle</sub>	277	lux
Measured power consumption in standby mode	P <sub>s</sub>	0	W
Measured power consumption off mode	P <sub>o</sub>	0.01	W
Sound power level	LWA	69	dB

**EN 61591 - Household range hoods and other cooking fume extractors – Methods for measuring performance**

**EN 60704-2-13 - Household and similar electrical appliances – Test code for the determination of airborne acoustical noise – Part 2-13: Particular requirements for range hoods**

**EN 50564 - Electrical and electronic household and office equipment. Measurement of low power consumption**

**Suggestions for a correct use in order to reduce the environmental impact:**

- Switch ON the hood at minimum speed when you start cooking and kept it running for few minutes after cooking is finished.
- Increase the speed only in case of large amount of smoke and vapour and use boost speed(s) only in extreme situations.
- Replace the charcoal filter(s) when necessary to maintain a good odour reduction efficiency.
- Clean the grease filter(s) when necessary to maintain a good grease filter efficiency.
- Use the maximum diameter of the ducting system indicated in this manual to optimize efficiency and minimize noise.